



Comb


Snap-In Blade Assembly
Step 1: Put part A into slot B with blade-side up.



Step 2: Press cutters back until you hear a click.



Snap-in Blade Disassembly
Press replaceable blade in thumbs and push forward in the direction of arrows.




Throw any broken blades away immediately. Blades should be replaced every three months.


Adjustable Guide combs
The trimmer comes with 2 adjustable guide combs for hair length preference.



Put on or take off the combs
Comb application:
Align the sides of the grooming length with the grooves on the underside of the comb attachment and slide it into place. Be sure to slide the comb onto the grooming head completely.




Comb removal: Drag open one side the comb. To keep combs from being damaged, pull lightly.



Note: Choose and attach the proper comb.

Maintenance

Snap-In Blade Cleaning **Body cleaning**
Step 1: Clean off hair scraps with cleaning brush. **Step 3:** Brush hair scraps in replaceable blade slots.




Step 2: Press down cutter frame handles in the direction of arrows and clean off hair scraps in between blades niches. **Step 4:** Wipe the shaver exterior with a soft, damp cloth.



Note: Turn the shaver off before cleaning by pressing the on/off button. The shaver is equipped with ceramic blades to help eliminate rusting. However, regular maintenance is highly recommended for optimal performance and longer life.


Shenzhen junjintong Intelligent Technology Co.,Ltd
Email: Support@nuoonu-tech.com
Add: Southwest of the intersection of Lantian Road and Huafa North Road Shenzhen,Guangdong, China

nuoonu
HC-W030



User Guide

Specification




Highlights
Safety replaceable snap-in blades.
High-quality safety ceramic blades resist scratching.

Less noise and low vibration
The motor is extremely quiet and features low vibration to keep you more comfortable while using it.

Guide combs assistance
Adjustable guide combs for customize hair length preference.



Detachable replaceable heads
Detachable replaceable heads make it easy to wipe off scrappy hair.



Technical Parameters
Power Source: USB charging
Battery type: 800 mAh
Charging time: About 2 hours
Working time after fully charged: 90 minutes



Accessories




Charging indicator

! Please charge the trimmer before initial use

Charging unit
Plug the usb charger in and fully charge the trimmer before using. This will take about 2 hours.

LED indicator
The LED indicator will flash while charging.
The unit is fully charged when battery indicator is steady on.

Reminder
Charge only when needed.
Do not overcharge.



Do not plug in USB cable with wet hands. Do not damage, stretch, bend or pull the charging cable. Turn trimmer off before disassembling the battery. After removing the battery do not connect the trimmer to the power cord. After removing the battery, take it to a designated collection center. Please store the shaver at room temperature.

成品尺寸：8*14.5cm
工艺：二折三页 风琴折
100G双胶印刷